***Congratulations on your purchase of a Security Boss® External Kennel Door.***

Vinyl Flap Door *(3 sided or 4 Sided)*
Professional Vinyl Flap Door
Kennel Clad™ Swing Kennel Door

**A SAFETY REMINDER!**
Always wear eye protection and gloves when appropriate.

**INSTALLATION INSTRUCTIONS**

The package you received should contain:

External Kennel Door
1/2" #6 Phillips Head Screws
1/2" #6 Security Screws for Tamper proof installations
7/64” Drill Bit
Allen Wrench *(included with flap models)*

Security Boss® Kennel Doors are intended to be installed over existing kennel opening passages. Verify that you have received the correct size by measuring the mounting flange of the pet door and comparing it to the existing opening. If you do not currently have an opening, or are enlarging an opening, trace the mounting flange of kennel door using a pencil. Use the dimension of the flange perimeter to determine your rough opening. Check both sides of the wall to make sure the area you cut is free of any obstructions. Be sure to follow local building codes when cutting and framing your specific application.

**Kennel Door Installation:**

**1.** Position frame on the exterior side of the pet opening. Be sure the opening in which the frame is being put into is square and plumb. If the frame is not mounted squarely in the opening, the door will not perform to its fullest potential. There should very little play or movement of the frame within the opening. Remove any excess movement using wood blocking and shims.

**2.** Level the frame at the top of the kennel opening. Attach the frame to the wall through the mounting flange. This is the fin that telescopes into the kennel opening passage. Attach the top of the Frame to the wood, drywall, or masonry using the appropriate fasteners.

**3.** Once the frame is attached to the wall at the top, verify the vertical sides are square with the top and ground using a level. It is important that both vertical sides are parallel to each other and square with the top. This will ensure that the swing panel or flap sits squarely within the frame and meets with the magnets in the frame. Shim the frame at the Mounting Flange as necessary to accomplish a proper fit.

**4.** Once the Frame is secured to the Wall, check the operation of the swing panel or flap in the opening. This movement should be unhindered. On flap models check that the magnets touch the Strike Plates on the Flap. For slight gaps between magnet and strike, the magnet can be lifted out of the frame channel a maximum of 1/16" to accommodate incorrect mounting.

**5.** Caulk or Seal the frame to the wall along the exterior frame perimeter.

Your Security Boss® External Kennel door is now installed.

**MAINTENANCE:**

The Security Boss® Manufacturing, LLC External Kennel doors are built to give years of durable service. The weather-stripping and vinyl flap replacement.

**Kennel Clad™ Swing Kennel Door**

The weather stripping on the door is held in place by sections of aluminum weather-stripping holder. The access points for replacing the pile are located in the center of the sides, bottom and top of the door. This hole is used to remove the existing weather stripping from that section of weather-stripping holder as well as install the new material. Retain the old weather-stripping sections for cutting the new material to the proper length.

**Vinyl Flap and Professional Vinyl Flap Door** ***(3 sided or 4 Sided)***

Using a flat blade screwdriver or pliers, gently pry the magnet assemblies from the painted frame. BE CAREFUL NOT TO DAMAGE THE MAGNET CARRIER OR SCRATCH THE FRAME. Once the magnets are removed, slide the old weather-stripping out of aluminum channel. Cut the new weather-stripping to the same length as the pieces that were removed. Gently slide the pile into the weather-stripping holder. Test fit all of the pile pieces into position; trim any excess before reinstalling magnet assemblies. If the magnet carrier is loose within the frame, gently pry the two legs at the opposite end of the magnet apart, be careful not to over extend the legs, then reinsert into the frame rail. The magnets are adjusted correctly when there is between 0" to 1/16" of airspace between the magnet and the strike plate on the flap.

Vinyl flap replacement is done by loosening the thumbscrews at the top of the frame with an Allen wrench. Once loose, remove the thumbscrews completely with your fingers. Then remove the flap. Put the binding post into the new flap or hinge-pile holder assembly and reinstall thumbscrews. It is important to be sure that the thumbscrews are not cross threaded when re installing them. Tighten the thumbscrews with an Allen wrench. Regularly check the thumbscrews for tightness as they may loosen with use.

**DISCLAIMER:**

**Child Safety:**
Security Boss Manufacturing, LLC… recommends that households with small children need to exercise proper judgment with leaving their children unattended in any area with a pet door. Pet Doors come with locking panels and locking devices, using these devices minimizes any risk, but does not replace proper parental supervision.

**Installation:**
We recommend that any consumer that installs their own pet door wear eye protection and be familiar with the construction procedures and tools of installing a pet door.

**Magnets:**
Virtually all doors use magnets for the activation of the pet door as well as in the sealing of the flaps. Customers with certain medical devices, for example; Pace Maker patients, should consult their physician.

If you have any questions or are unclear about these safety statements please call our Distributor: Moore Pet Supplies LLC, at 1-800-829-7876.

## Security Boss Kennel Door Warranty

Security Boss® Manufacturing LLC guarantees to the original consumer / purchaser of our Kennel Doors (Insulated Guillotine, Standard Guillotine, 4-Sided Exterior and 3-Sided Exterior) a **limited 1-year warranty** for their component parts to be free of defects on materials and workmanship for a period of 1-year from the date of purchase.

For a period of One year from the date of purchase, any defective product or part may be sent, freight prepaid, to **Security Boss® Manufacturing LLC., C/O *Moore Pet Supplies** for replacement or repair. Proof of purchase date must accompany any returned item. Manufacturer's liability on any claim shall not exceed the cost of the product. Security Boss® Manufacturing does not cover or pay for the loss of time, inconvenience, loss of use of your product, or any incidental or consequential damages.

**Damage caused by accident, improper installation or abuse, including damage caused by pets, is specifically excluded from this warranty.**

This warranty replaces any and all previous warranties, either written, oral, or implied, and is the only warranty made by this company.

*Moore Pet Supplies is not affiliated with or has any liability but acts only as a processing agent for all warranted items returned to Security Boss® Manufacturing LLC.

For questions regarding our warranty or please contact Moore Pet Customer Care at 1-800-829-7876.

**Special Notes Regarding Warranty:**

<u>Guillotine Kennel Doors:</u>
*Improper use of the Security Boss® Guillotine Kennel Doors is not covered under this warranty. These products are designed to be used with the included cable system hardware to control each doors movement during opening and closing. Allowing the door to free fall to the closed position constitutes Improper Use. Components on the Security Boss® Guillotine Kennel Doors are replaceable to allow the customer to maintain the products.*

**Destructive behavior by kennel occupants is not covered under warranty.**

<u>3 & 4-Sided Exterior Kennel Doors:</u>
*Improper use of the Security Boss® 3 4-Sided Exterior Kennel Doors are not covered under this warranty. Components on these Kennel Doors are replaceable so that they can be maintained. Flaps are covered under this warranty for 1-year.*

**Destructive behavior by kennel occupants is not covered under warranty.**